

An Overview of Experiments in The Entry Systems Modeling Project

Sam Chen, Prof. Francesco Panerai

Department of Aerospace Engineering, University of Illinois at Urbana-Champaign

Kristin Price, John R. Onan, Prof. Mike Renfro, Prof.

Sean C. C. Bailey, & Prof. Alex Martin

Mechanical and Aerospace Engineering, University of Kentucky

Dr. Brody K. Bessire

NASA Ames Research Center



AIAA SciTech 2023

Agenda

1) Varcum Oxidation Studies

- **Microstructure of FiberForm**
- **Comparison of FiberForm Constituents**

2) Arc-Jet / Material Response

- **Spallation Testing at AHF**

3) PICA-NuSil

- **HyMETS Testing**
- **Preliminary Pyrolysis Gas Measurements**

Differential Oxidation of FiberForm Constituents

Sam Chen, Prof. Francesco Panerai

Department of Aerospace Engineering, University of Illinois at Urbana-Champaign




NASA POC: Brody Bessire



Differential Oxidation of FiberForm Constituents

S.E.M. Images of Charred PICA (PSO3) (Presumed to be free of SiOC or SiO₂)



Credit: Jose F. Chavez-Garcia and Brody K. Bessire

- FiberForm is composed of a carbon fiber network bound together with a charred phenolic binder (varcum).
- PICA is manufactured by impregnating FiberForm with a phenolic resin (SC-1008).
- Charred PICA consists of regions of pyrolyzed phenolic resin and carbon fibers that have eroded due to oxidation.
- Question: Does varcum oxidize at a different rate than the carbon fibers of FiberForm?
- Question: If differential oxidation of FiberForm constituents is observed then is this a significant channel for spallation?
- First step: Isolate constituents of FiberForm and measure oxidation rates under well-controlled experimental conditions.



Isolating Constituents of FiberForm

- Carbonize varcum under relevant conditions and provide a surface that is amenable to spectroscopic measurements.

Cured Varcum




- Cure Varcum Powder @ 160 °C for 30 minute.
- Crush cured varcum with mortar and pestle.

High-Temperature Tube Furnace




- Carbonize varcum powder in graphite crucible @ 1500 °C for 3 hours.

Varcum Char Results




- Process produces a pellet with a flat end.




Raman Spectroscopy

- “D” Peak at 1350 cm^{-1} increases in sharpness with increasing order.
- $I(D)/I(G)$ ratio increases with heat treatment.
- Amorphous content decreases as peaks at 1200 cm^{-1} and 1350 cm^{-1} shrink.



Thermogravimetric Analysis / Oxidation Rates

- Oxidation rate generally increases with higher oxidation temperatures
- Peak oxidation rate increases and time to reach peak rate decreases with higher isothermal oxidation conditions



AIAA SciTech 2023

Agenda

1) Varcum Oxidation Studies

- ~~Microstructure of FiberForm~~
- ~~Comparison of FiberForm Constituents~~

2) Arc-Jet / Material Response

- Spallation Testing at AHF

3) PICA-NuSil

- HyMETS Testing
- Preliminary Pyrolysis Gas Measurements


AHF Experiments

Spallation Experiments at AHF

**Kristin Price, John R. Onan, Prof. Mike Renfro,
Prof. Sean C. C. Bailey, & Prof. Alex Martin**

Mechanical and Aerospace Engineering, University of Kentucky

Kristen Price, “Characterization of spalled particles resulting from arc-jet tests” – tomorrow (TP-15)




NASA POC: Eric Stern & Brody Bessire



AHF Test Campaign / Spallation Test





- **Aim**
 - Capture spalled particles to identify size and weight
- **Approach**
 - 16 PICA and FiberForm samples, at low heating air conditions
 - Particles will be collected by a reservoir at the back of the sample
 - Shadowgraph will be used to track particles
 - High-speed camera will be focused on ejection sites



POC: Kristen Price, John, R. Onan, Sean C.C. Bailey, Alex Martin, Mike Renfro

AHF Test Campaign / Spallation Test

- **Spallation testing:**
 - Compiled high-speed images match with pre-test spallation models
 - Physically captured particles are within bounds of previously estimated particle sizes



POC: Kristen Price, John, R. Onan, Sean C.C. Bailey, Alex Martin, Mike Renfro

AIAA SciTech 2023

Agenda

~~1) Varcum Oxidation Studies~~

- ~~• Microstructure of FiberForm~~
- ~~• Comparison of FiberForm Constituents~~

~~2) Arc-Jet / Material Response~~

- ~~• Spallation Testing at AHF~~

3) PICA-NuSil

- HyMETS Testing
- Preliminary Pyrolysis Gas Measurements

PICA-NuSiI


MSL Heat Shield



NuSiI (CV-1144-0)




Surface-Temperature Discontinuity



Surface Temperature of PICA with , NuSiI Coating. (85 W cm^{-2})

- PICA is friable.
- An overcoat of NuSiI (CV-1144-0) is applied to the surface to mitigate phenolic particulate shedding.
- State of the art material response models are under development to account for the surface temperature phenomenon.
- Jeremie Meurisse, “3D ablation modeling of silicone-coated heatshield compared to MEDLI2 in-flight data” – tomorrow at 2:00 P.M. (TP-18)

PICA-NuSi




- Mini sphere-cone models of PICA-NuSi were subjected to arc-jet testing at the HyMETs facility located at NASA Langley in Virginia.
- Pyrometer data, emission spectra, and high-speed video reveal that the coating survives on the surface for several seconds before decomposing.
- A second round of HyMETs experiments will focus on testing PICA-NuSi in the CO₂ environment.

PICA + NuSiI





Siloxane Copolymer Backbone



$n \approx 262 \pm 6$ monomer units




Oxime Crosslinking Agent




Do components of NuSiI react with PICA?

Possible Reactions Under Ambient Conditions

Crosslinking compounds reacts with hydroxyl functional units of phenolic resin.



- 5 wt. % oxime mixed with naphtha.
- 2 mm. dia. rod of PICA soaked in solution overnight.
- PICA + oxime cured in open air for 1 week.
- Attenuated Total Reflectance (ATR) spectra reveal a decreased intensity of OH stretch ($3000\text{ cm}^{-1} - 3550\text{ cm}^{-1}$).




PICA

- Dominant pyrolysis products:

- H_2 , CH_4 , H_2O , CO .
- Signal from polymer backbone fragments (e.g., phenol, cresol).
- m/z 18 – Water evolves as a product of ether bond formation between hydroxyl functional groups of the phenolic polymer.
- m/z 16, 28 – Peak evolution of methane and carbon monoxide at $t \approx 5.5$ minutes.
- m/z 2 – Peak evolution of Hydrogen at 7.7 min.
- m/z 2, 28 – Hydrogen and Carbon Monoxide rise again after $T > 1,100$ °C.

Thermal Decomposition of PICA



- Char yield typically 80 wt. %.

Pyrolysis Gas Testing


PICA + 45 wt. % NuSil

- Mixed 45 wt. % of NuSil with naphtha.
- 2 mm dia. rod of PICA soaked in NuSil solution overnight.
- PICA + NuSil solution cured in open air for 1 week.

Dominant pyrolysis products

- H_2 , CH_4 , H_2O , CO .
- m/z 18 – Low temperature evolution of water is bimodal. Evolution of water may be reduced in the presence of NuSil.
- m/z 2, 16 – Evolution of hydrogen and methane are bimodal. Peak methane production is shifted to higher temperature.
- m/z 28 – Evolution of carbon monoxide at low and high temperature.

Thermal Decomposition of PICA-N



- NuSil reacts with PICA at high temperature.

End